

About My Go-Ped®

Model _____

Serial # _____

Motor _____

Motor Serial # _____

Gas:Oil Ratio _____

Dealer Service
Center _____



Gas Powered Operator's Manual

Contains IMPORTANT and VITAL User Information

Read entire Operator's Manual
before operation of your Gas Powered Go-Ped®

**Express
Your
Freedom**



Patmont Motor Werks

Made in the U.S.A. Since 1985



WHAT WE GUARANTEE AND WHAT YOU PROMISE US

Patmont Motor Werks, a Nevada Corporation (hereinafter referred to as "P.M.W.") expressly warrants that each of its products is free from defects in material and workmanship under normal operating conditions and according to proper use for a period of 90 days from the date of original purchase. Frame and fork guaranteed for 2 years against factory defects and workmanship. Normal operating conditions require adequate fuel/oil ratio and /or routine care and maintenance by the purchaser of the product. Proper use means that the P.M.W. transportation product is to be used only in the manner intended for personal transportation of a single rider with proper safety equipment described on the RED SAFETY WARNING LABEL affixed to the product. P.M.W. Transportation Products are intended for use only with the proper safety equipment on smoothly paved, safe, dry, non-oily surfaces in accordance with local regulations during daylight hours. In express consideration for purchasers execution of the limited warranty and liability agreement, P.M.W. will repair or replace any part or component, other than tires, of the P.M.W. transportation product free of charge to the original purchaser who registers his/her product under the warranty program. Warranty service can be obtained by calling your local dealer or the Tech. Line at (925) 373-7827 and following the instructions given by the service representative. Shipping costs will be at the purchasers' expense. This warranty does not apply to tire wear, operation under abnormal conditions or damage to the vehicle brought on by improper use. Racing, competitive or commercial use, or modification of the product shall void this express limited warranty. All models with adjustable carburetors are not warranted for piston/cylinder seizure due to adjustability of the carburetor, which can be tampered by end user. Engine crankshaft failures on spindle drive models are not covered under warranty due to varying riding styles and the adjustability of the tire to spindle pressure by end user. Purchaser herewith acknowledges: (a) P.M.W. assumes no liability for any misuse of any of its transportation products. (b) Under this limited warranty and liability agreement P.M.W. shall have no obligation and the purchaser or user shall have no remedy against P.M.W., its officers, agents or assigns for any damages, including without limitation, incidental, consequential, special, punitive damages arising from direct or indirect injury to person or property, or any other loss, whether or not occasioned by negligence, or otherwise, on the part of P.M.W. (c) Purchaser acknowledges that there is an inherent risk in the operation of motorcycles, bicycles, mopeds, and all P.M.W. transportation products, and herewith assumes the risk of any injury arising from operation of any P.M.W. transportation product.

Original owner will indemnify and hold P.M.W. harmless and will take full responsibility for conveying all safety warnings, instructions, and limited warranty if unit is sold, lent, or otherwise transferred to other persons and will indemnify P.M.W. from any claims against it for original owners' failure to do so. THE EXPRESS LIMITED WARRANTY DESCRIBED ABOVE SHALL BE EXCLUSIVE AND THERE IS NO OTHER WARRANTY OR LIABILITY, EXPRESS OR IMPLIED, ARISING BY LAW OR OTHERWISE AND WHETHER OR NOT OCCASIONED BY SELLER'S NEGLIGENCE. THERE IS NO IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THOSE EXPRESSLY STATED HEREIN.

NOTICE: Some states do not allow the exclusion or limitation of incidental or consequential damages and some states do not allow limitation on how long an implied warranty lasts, therefore, some of the above limitations may not apply to you.

NOTICE: Your Homeowners Insurance may not cover either Direct or Third Party Liability Claims arising from use of this or any other Go-Ped® product.

PLEASE ACKNOWLEDGE THAT YOU HAVE READ AND UNDERSTAND EACH WARNING BY PLACING YOUR INITIALS IN EACH BOX

_____ This device does not conform to Federal Motor Vehicle Safety standards and is not intended for operation on public streets, roads or highways.

_____ Safety helmet, goggles, gloves, elbow, and knee pads, appropriate shoes, and bright clothing must be worn while operating this device to reduce potential of injury.

_____ Do not operate this device in traffic, or on wet, frozen, oily or unpaved surfaces. Avoid uneven surfaces, chuckholes, surface cracks, obstacles and night or conditions of darkness.

_____ Never carry passengers and objects that can hinder your abilities to safely operate your vehicle.

_____ Pregnant persons should not use this product.

_____ Never use alcohol or drugs before or while operating this device. They slow reaction time and impair judgment.

_____ This product should not be used by minors without adult supervision.

_____ High speeds, jumps and trick maneuvers are dangerous and could result in loss of control and other accidents.

_____ When accelerating or climbing hills, you will need to lean forward, under braking conditions you will need to lean back, to keep wheels in contact with the ground.

_____ Never permit a guest to use this device unless the guest has read the user manual and all labels.

_____ I agree to provide my guest with helmet, safety goggles, elbow pads, and knee pads.

_____ Engine shut off switch is available for rear wheel braking or for use in the event of throttle failure or other emergency when engine shut off is desired.

_____ This product should not be used by persons unwilling or unable to take responsibility for their own actions.

_____ Read all additional warnings and instructions in user manual before operating this P.M.W. product.

_____ Adults purchasing this Unit for Children, inclusive but not limited to a Parent or Guardian, assume direct liability for injury to the child, or to third parties to whom the child entrusts the vehicle.

_____ Homeowners Insurance may not cover either Direct or Third Party Liability Claims Arising from Use of this or any other Go-Ped® product.

_____ I herewith promise not to entrust this vehicle to any child under 16 (Sixteen) years of age.

_____ Never remove exhaust tube from manifold of engine or serious damage to your Go-Ped and yourself will result.

WE SETTLE ARGUMENTS BY ARBITRATION
ANY DISPUTE HEREUNDER WILL BE RESOLVED THROUGH BINDING ARBITRATION IN THE CITY OF RENO, COUNTY OF WASHOE, NEVADA, ACCORDING TO THE RULES GERMANE TO ARBITRATIONS CONTAINED IN REVISED NEVADA STATUTES.

_____ (Purchaser's Initials Required)

NOTICE: BY SIGNING BELOW YOU ARE AGREEING TO HAVE ANY DISPUTES ARISING OUT OF THE MATTERS INCLUDED IN THE 'ARBITRATION OF DISPUTES' PROVISION DECIDED BY NEUTRAL ARBITRATION AS PROVIDED BY NEVADA LAW, AND THAT YOU ARE GIVING UP ANY RIGHTS YOU MIGHT POSSESS TO HAVE THE DISPUTE LITIGATED IN A COURT OR JURY TRIAL. BY SIGNING BELOW YOU ARE GIVING UP YOUR JUDICIAL RIGHTS TO DISCOVERY AND APPEAL, UNLESS THOSE RIGHTS ARE SPECIFICALLY INCLUDED IN THE 'ARBITRATION OF DISPUTES' PROVISION. IF YOU REFUSE TO SUBMIT TO ARBITRATION AFTER AGREEING TO THIS PROVISION, YOU MAY BE COMPELLED TO ARBITRATE UNDER THE AUTHORITY OF THE NEVADA CODE OF CIVIL PROCEDURE. YOUR AGREEMENT TO THIS ARBITRATION PROVISION IS VOLUNTARY.

You should feel free to consult an attorney before signing this limited warranty and liability agreement.

I have read understood and agreed to be bound by the limited warranty and liability agreement above and agree to submit disputes arising out of matters included in the arbitration of disputes provision to neutral arbitration.

California Go-Ped®/Patmont Motor Werks Limited Warranty

EMISSION RELATED PARTS, FOR TWO (2) YEARS FROM THE DATE OF ORIGINAL DELIVERY, PATMONT MOTOR WERKS (THE COMPANY), THROUGH ANY GO-PED® DEALER, WILL REPAIR OR REPLACE, FREE OF CHARGE, FOR THE ORIGINAL AND EACH SUBSEQUENT PURCHASER, ANY PART OR PARTS FOUND TO BE DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP, EMISSION-RELATED PARTS ARE:

THE CARBURETOR ASSY, COIL ASSY, ROTOR, SPARK PLUG, AIR FILTER, FUEL FILTER, INTAKE MANIFOLD, AND THE GASKETS

ALL OTHER PARTS EXCEPT ABOVE PARTS, FROM THE DATE OF ORIGINAL DELIVERY, THE COMPANY, THROUGH ANY GO-PED® DEALER WILL REPAIR OR REPLACE, FREE OF CHARGE, FOR THE ORIGINAL PURCHASER. ANY PART OF PARTS FOUND TO BE DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP.

THIS IS THE EXCLUSIVE REMEDY:

-THE PURCHASER SHALL BEAR COSTS OF TRANSPORTING THE UNIT TO AND FROM THE GO-PED® DEALER.

-THE PURCHASER SHALL NOT BE CHARGED FOR DIAGNOSTIC LABOR WHICH LEADS TO THE DETERMINATION THAT A WARRANTED PART IS DEFECTIVE, IF THE DIAGNOSTIC WORK IS PERFORMED AT THE GO-PED® DEALER.

-THE PURCHASER OR OWNER IS RESPONSIBLE FOR THE PERFORMANCE OF THE REQUIRED MAINTENANCE AS DEFINED BY THE MANUFACTURER IN THE OWNER/OPERATOR MANUAL.

-ANY WARRANTED PART WHICH IS NOT SCHEDULED FOR REPLACEMENT AS REQUIRED MAINTENANCE, OR WHICH IS SCHEDULED ONLY FOR REGULAR INSPECTION TO THE EFFECT OF "REPAIR OR REPLACE AS NECESSARY" SHALL BE WARRANTED FOR THE WARRANTY PERIOD. ANY WARRANTED PART WHICH IS SCHEDULED FOR REPLACEMENT AS REQUIRED MAINTENANCE SHALL BE WARRANTED FOR THE PERIOD OF TIME UP TO THE FIRST SCHEDULED REPLACEMENT POINT FOR THE PART.

-ANY REPLACEMENT PART THAT IS EQUIVALENT IN PERFORMANCE AND DURABILITY MAY BE USED IN NON-WARRANTY MAINTENANCE OR REPAIRS, AND SHALL NOT REDUCE THE WARRANTY OBLIGATION OF THE COMPANY.

-THE COMPANY IS LIABLE FOR DAMAGES TO OTHER ENGINE COMPONENTS CAUSED BY THE FAILURE OF A WARRANTED PART STILL UNDER WARRANTY.

-THE WARRANTY DOES NOT APPLY TO THOSE UNITS WHICH HAVE BEEN DAMAGED BY NEGLIGENCE OF INSTRUCTION LISTED IN THE OWNER/OPERATOR MANUAL FOR PROPER USE AND MAINTENANCE OF THE UNIT, ACCIDENT, MISHANDLING, ALTERATION, ABUSE, IMPROPER LUBRICATION, USE OF ANY PARTS OR ACCESSORIES OTHER THAN THOSE SPECIFIED BY THE COMPANY, OR OTHER CAUSES BEYOND THE COMPANY'S CONTROL.

-THIS WARRANTY DOES NOT COVER THOSE PARTS REPLACED BY NORMAL WEAR OR HARMLESS CHANGES IN THEIR APPEARANCE.

-THERE ARE NO OTHER EXPRESS WARRANTIES.

-IMPLIED WARRANTIES INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE LIMITED TO 90 DAYS FROM THE ORIGINAL DELIVERY DATE.

-LIABILITIES FOR INCIDENTAL OR CONSEQUENTIAL DAMAGE UNDER ANY AND ALL WARRANTIES ARE EXCLUDED.

-SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS OR EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU.

-THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

-IF YOU NEED TO OBTAIN INFORMATION ABOUT THE NEAREST SERVICE CENTER, PLEASE CALL PATMONT MOTOR WERKS AT (925) 373-7827 or visit www.goped.com

IMPORTANT: YOU WILL RECEIVE A WARRANTY REGISTRATION FORM AT TIME OF PURCHASE. PLEASE FILL OUT THE FORM AND SEND IT TO GO-PED®/PATMONT MOTOR WERKS WITHIN SEVEN (7) DAYS. BE SURE TO KEEP A COPY FOR YOUR RECORDS.

9.4 Suspension:

For products with suspension there are a few adjustment procedures you need to be aware of:

- Although your suspension is adjustable it comes pre-adjusted and ready to ride from the factory.

- To make adjustments to your suspension, screw the adjustment screws in CW (tighten) for stiffer suspension feel, or out CCW (loosen) for a more plush feel.

- It may take a bit of riding for the suspension to adapt completely to the adjustments made. Adjustments should be made in small increments and a light thread lock fluid may be needed to secure screw setting.

- The nut in the middle of the suspension "knuckle" is for the disassembly of the suspension. It takes special tools to assemble the suspension properly so consult an authorized Go-Ped® Dealer before attempting any replacement of internal suspension parts. However, tightening and or loosening this center nut also stiffens and loosens the suspension so for models without the 4 adjustment screws you can tighten CW this center nut for a stiffer feel or loosen CCW for a softer one. You just need to make sure that the nut does not come off and liquid thread lock like Loctite is recommended if you are loosening for a softer feel.



Contents

Section 1: Important Information

- 1.1) About this Manual
- 1.2) A SPECIAL NOTE FOR PARENTS

Section 2: Safety

- 2.1) Equipment Safety
- 2.2) Mechanical Safety Check
- 2.3) Scooting Safety
- 2.4) Rules to Scoot By
- 2.5) Stunts, Wheelies, or Jumps
- 2.6) Wet Weather Riding
- 2.7) Night Riding

Section 3: Assembly

- 3.1) Pre-assembled scooters
- 3.2) Some assembly required
- 3.3) Folding Feature

Section 4: Oil & Fuel Information

- 4.1) Oil and Fuel Mixing Instructions
- 4.2) Fueling & Pre-Operation

Section 5: Controls

Section 6: Starting

- 6.1) Starting your non chain drive model
- 6.2) Starting your chain drive models
- 6.3) Starting your Bigfoot™, Go-Quad®, Super Go-Quad™
- 6.4) "Easy Pull" pull starter
- 6.5) Engine Starting Instructions
- 6.6) Motorized Riding

Section 7: Free Wheel Scooting

- 7.1) Non-Chain Driven Models
- 7.2) Bigfoot™
- 7.3) Chain Drive Models

Section 8: Maintenance and Parts

- 8.1) Service and Maintenance Schedule (new engine Brake-In)
- 8.2) Special Engine Maintenance

Section 9: Adjustment

- 9.1) Brakes
- 9.2) Wheels
- 9.3) Chain tension adjustments
- 9.4) Suspension Adjustment

Thank you for your recent acquisition of a California Go-Ped® brand product!

We are very happy and proud to welcome you to California Go-Ped®, the World's Best in Extreme Fun, Innovation and Quality. By choosing California Go-Ped®, you have selected the highest quality scooter products in the World, which have been handcrafted in the USA since 1985, using aircraft grade materials and the highest quality components.

As the leader in innovation, design and performance California Go-Ped® has paved the way for personal transportation by producing lightweight, fuel efficient, durable, performance minded, and well-balanced machines.

As a new Go-Ped® owner and User, you now have access to the widest dealer network, thousands of parts for your Go-Ped®, complete warranty coverage and instant access to service.

You are now part of the fastest growing community of scooter enthusiasts in the world.

A technical hot line is available for further assistance 925-373-6309. You can also find technical help videos and replacement parts by visiting the "FAQ" and "Products" pages at www.goped.com

Attention: To find more information, news, replacement parts, accessories, and support on California Go-Ped® Brand Products, please visit us on-line at www.goped.com. You can also become a "Go-Ped Brand Products" fan on FaceBook, follow us on Twitter "Go_Ped" and or connect, have discussions or just see what other Go-Ped owners and fans are saying at

www.gopednation.com

Section 1: Important Information

1.1 About this Manual

Why you should read this manual:

This manual was written to help you understand the operation and maintenance of your vehicle. It's important for you to understand your new scooter/kart, its features and operations so that from your first ride you will get the most from your new scooter/kart and form proper habits to keep it maintained for optimum performance and safety for many years to come.

Keep this manual. Refer to it often and use it to instruct other users. If you loan out your Go-Ped® also loan them this manual.

It is also important that your first ride on a new scooter/kart is taken in a controlled environment, away from vehicles, obstacles and other hazards.

Even if you have previous experience with motorized scooters, vehicles, bikes, and the like, you probably need an update of your scooting habits, knowledge and assumptions. There are many changes in technologies and construction which affect function, handling, performance and safety of your scooter/kart.



General Warning: Scooting/karting can be a hazardous activity even under the best of circumstances. Proper maintenance of your scooter/kart is your responsibility as it helps reduce the risk of injury. This manual contains many "Warnings" and "Cautions" concerning the possible consequences of failure to follow instructions, perform maintenance, or inspect your scooter. Any fall can result in serious injury or even death, so operating within the guidelines outlined in this manual will help reduce those risks.

Attention:

- The status of the Go-Ped® as a "motor vehicle" varies from region to region and is subject to drivers licensing, insurance requirements and registration.
- You should check with a reliable authority in your area to see if the Go-Ped® must be registered as a motor vehicle. Your police department or local department of motor vehicles may be able to answer your questions or direct you to a reliable authority.
- Your insurance policies may not provide coverage for accidents involving the use of this vehicle. To determine if coverage is provided you should contact your insurance company or agent.
- **The recommended age and minimum weight for the Go-Ped® is 16 years of age or older and 100 pounds**, but this is subject to the physical coordination of the rider, the ability of the rider to wear protective gear, use good decision making ability, and to take responsibility for their own actions.

1.2 A SPECIAL NOTE FOR PARENTS

It's a tragic fact that most children are more likely to have an accident. As a parent or guardian, you bear the responsibility for the activities and safety of your minor child. Among these responsibilities are to make sure that the scooter/kart which your child is riding is properly fitted to the child; that it is in good repair and in safe operating condition; that you and your child have learned, understand and obey not only the applicable local motor vehicle and traffic laws, but also the common sense rules of safe and responsible scooting. As a parent you should read this manual and go over all key points with your child before letting your child ride the scooter/kart.

Section 2: Safety

2.1 Equipment Safety



Warning: Many States or regions require specific safety devices or equipment. It is your responsibility to familiarize yourself with laws of the state or region in which you ride and to comply with all applicable laws, including properly equipping yourself and your scooter/kart.

5) Lock down quick release lever with snug pressure. This will lock axle in position until readjustment is required again. You are now finished adjusting the rear wheel.

CAUTION: Rear wheel adjustment will be required more frequently when tire is new and when scooter is driven aggressively. Adjust frequently to prevent drive system slippage and prematurely wearing out the tire. If drive system is allowed to slip excessively, high temperatures/friction will result in damage to the drive spindle and premature tire wear, and extreme and uneven tire wear can result, causing uneven overloading to engine crankshaft and bearing. Refer to "Adjusting the rear wheel" section in this manual to correct drive system engagement issues.



9.3 Chain tension Adjustment


Proper chain care and maintenance is essential to longevity and wear of the drive components on your chain drive scooter.

- Make sure that the sprockets are perfectly aligned to each other. Use a long straight edge or you can check this visually by lining up the rear sprocket with the front and seeing that the chain is straight.

- **For scooters equipped with a pivoting motor mount chain tension adjustment:**

The motor mount on units with a pivoting motor mount allows chain tension adjustment to accommodate chain stretch and/or sprocket wear. To adjust the motor mount simply loosen the two nylock nuts located on the motor mount under the motor and pivot the motor mount forward until the specified chain tension is achieved. Once the desired tension is achieved, retighten the nuts. Failure to keep the chain properly adjusted will result in premature sprocket and chain wear. The sprockets may be aligned by adding or removing washers between the rear wheel and the frame. Tighten chain so that there is approximately 1/4 in of chain play between the two sprockets.

- **More about chain tension:** Some motor mounts are equipped with a single carriage bolt which helps to hold the motor in place. Adjust the bolt until the head of the bolt touches the frame, then lock the bolt in place with the locknut.



CAUTION: Tightening the chain more than necessary will cause your drive components to wear prematurely and add performance reducing drive system friction.



- The chain should be lubricated before each ride.
- Your chain should be clean. A safe cleaning solvent can be used but the chain must be oiled once it is dry.
- To reduce dirt and grime buildup and overspray on rear brake components, never over lubricate the chain.
- Sprockets should be periodically checked for damage and wear. If you notice that there is any damage to the sprockets or a tooth missing it should be replaced immediately.

CAUTION: Never lubricate chain while motor is running. Always keep fingers, clothing, and other objects clear of any rotating chain or wheel.



Twist lever and cable: On the Bigfoot™ your twist lever engages or disengages the motor's drive component. With the lever in the full up position the drive spindle must not touch the wheel in anyway. When the lever is in the full down position you should have ample slack in the cable to allow for spindle to be fully engaged with the tire. There are adjustment barrels on each end of the cable housing for the twist lever.

9.2 Wheels

Front wheel removal: 1) Make a note of the location for the washers used on the front axle. 2) Remove the axle nut. 3) Slide the axle bolt out and remove wheel.

Rear Wheel Removal: 1) Make a note of the location for the washers used on the front axle. 2) Remove the axle nut. 3) Slide the axle bolt out and remove wheel. Note: On some units the fender can pivot clear of the wheel for easy access once the axle nut is removed.



CAUTION: Only use original equipment for your Go-Ped®. Substituting with other brands may have unforeseen dangers that could cause damage, making your Go-Ped® perform in an unsafe manner, causing damage and/or personal injury.

Replacing the solid rubber tire : 1) Use hacksaw and carefully cut off the old tire from rim. 2) Take new tire and dip in body of water. 3) Work one side of tire all the way around the rim. 4) Place wheel on ground over a soft surface such as an old piece of carpet/cardboard. 5) Very carefully, but firmly, compress/stomp the assembly together.



Warning: Do not use any grease, oil, or solvents to help install rubber tire.

Note: Only use original Go-Ped® tires. Replacing the rubber tire takes some practice. If you are having trouble, have your authorized Go-Ped® dealer teach you, or have them perform this task for you.

Replacing pneumatic tires and tubes: The tires and tubes are critical components requiring precise reassembly to insure proper alignments. An authorized Go-Ped® dealer using OEM parts should do this operation.



Warning: Completely deflate wheel before wheel disassembly or any work on the wheel. Failing to do so can result in serious injury.

Adjusting the rear wheel: For non-chain driven models only. To get maximum life out of your tires and scooter you should follow these directions and adjust frequently.

1) Open quick release axle to unlock and allow free movement of wheel (axle nut may need to be loosened also).

2) With Quick Release Axle opened and loosened, rotate the snail shaped engine protection washer (EPW) down, away from rear gas tank support stud.

3) Apply approx. 75 lb of weight to rear part of Go-Ped® deck (one knee on the "D" works pretty good) with rear wheel on the ground. (To apply proper tire/spindle contact).

4) Rotate the snail shaped engine protection washer (EPW) up to contact rear gas tank stud while weight is still applied, this will prevent overload to engine bearings and crankshaft.

A. Helmets: While not all States or regions require riders to wear approved protective head gear, common sense dictates that you should wear a DOT, Snell, BSI or CPSC approved helmet. Most serious incidences involve head injuries which might have been avoided if the rider had worn a helmet.



Your authorized Go-Ped® dealer may have a variety of attractive approved helmets, and can recommend one to suit your needs. Make sure that it fits correctly, is worn correctly and is properly secured. Ask your dealer to help with the fit and adjustment of your helmet, or refer to the owner's manual provided with the helmet. Buckle Up!

WARNING: Always wear an approved helmet when riding your scooter. Helmet should be worn correctly as outlined in the owner's manual for the helmet. Failure to wear an approved helmet can result in serious injury or death.



B. Protective pads: Elbow pads, knee pads, and wrist guards are not required by most states or regions. Again, common sense dictates that you should wear protective pads to help protect against injury. Your authorized Go-Ped® dealer may have a variety of protective pads, and can recommend one to suit your needs. A good set of pads should fit comfortably, stay in position at all times and not have any excess strapping, Velcro®, or other protrusions to catch on anything that can cause you to lose control of your scooter/kart.



C. Shoes: Your shoes should have good grip, protection, and support. Your shoes should have adequate strapping or laces so they stay on your feet. Make sure that laces or other strapping can not catch or hang-up on any part of the scooter or other objects. Never ride barefoot or wear sandals when operating the scooter.

D. Clothing: Being seen is very important. Brightly colored, reflective helmets and clothing will help make riders more noticeable. Clothing should not be so loose that it can catch on moving parts or be snagged on other objects.

E. Eye protection: Any kind of riding can involve airborne debris, dust, and bugs, so common sense dictates that you should wear protective eyewear with protective lenses.

F. Reflectors: Reflectors are important safety devices designed to reflect light in a way that helps to be seen. The reflectors are intended to enhance the visibility of the scooter but may not meet reflector requirements for your area.

WARNING: Do not remove the reflectors from your scooter. Removing reflectors may reduce visibility to others. Reflectors are not suitable for use as lights. Riding at dawn, dusk, or night is not recommended and presents a serious risk to the rider, regardless of what measures you have taken.



2.2 Mechanical Safety Check

Here is a simple procedure you should get in the habit of before you get on your scooter:

A. Nuts, bolts, and structural: Pick your scooter off the ground a few inches and bounce it. Do a quick visual and tactile inspection of the whole scooter/kart. Make sure you look at all visible nuts, bolts and structural welds. If anything sounds, feels or looks loose or shows signs of stress then replace, or secure them. If you're not sure, ask someone with experience to check, or ask an authorized dealer to show you what to look for in a mechanical safety check.

WARNING: Inspect unit before each use. Make any required adjustments, and replace or repair any item that may need it.



B. Tires and Wheels: Check that pneumatic tires are properly inflated. Refer to the sidewall of the tire for recommended PSI. Checking PSI using a tire pressure gauge is recommended but you can also bounce your weight on the scooter and compare tire deflection to how it looks when you know the tires are properly inflated. Spin the wheels and check that the tires have not yet reached the wear marks on the tires, have ripped, torn, or show any signs of distress and replace as necessary. Make sure the wheels spin freely and true. If wheels wobble or rub the brakes then make adjustment or repairs before operation.

C. Brakes: Squeeze the brake levers and check that they are getting proper contact with the tire or disc (depending on model). Full braking force is applied when you squeeze the lever and the lever cannot touch the handle bar or grip. The brakes should not interfere with the rotation of the wheel when not applied. Make sure that the brake caliper gets full contact with the rubber tire or disc. Make sure that all brake surfaces are clean and free of debris. Do not ride the scooter until the brakes are properly adjusted.



WARNING: Never attempt to ride your vehicle without properly adjusted brakes.

D. Control levers and cables: Familiarize yourself with the levers and controls. Squeeze and or twist all levers/controls and make sure they are functioning properly. If they stick, move at the base, or do not get full range of motion, make adjustments as necessary or take to an authorized Go-Ped® dealer for service. Do not ride the scooter until the control levers and cables are properly adjusted.

Control levers are originally positioned where they work best for most people. The angle of the controls can be changed to better suit you. Ask your dealer to show you how, or learn how to make the adjustments yourself.



WARNING: Never attempt to ride your vehicle without properly adjusted controls and cables.

E. Engine: Check the idle speed. Direct drive models will go about 2 to 3 miles per hour at idle with the drive engaged. Make sure that the air filter is clean and clean if necessary.

Due to engine vibration, nuts and bolts can become loose. Make sure that carburetor, muffler, motor mounts and other fasteners are securely fastened and tighten if necessary.



WARNING: Muffler and exhaust components are hot and you should allow ample time to allow for cooling before performing any adjustments or repairs to the motor.

2.3 Scooting Safety



CAUTION: Like most sports, scooting/karting involves risk of injury and damage. By choosing to ride a scooter/kart you assume the responsibility for that risk. This makes it extremely important that you know, understand, and practice the rules of safe and responsible riding.

Scooting can be an environmentally useful, safe and fun way of reducing traffic congestion.



WARNING: Karts are designed for recreational use only! They should never be used on streets



CAUTION: Modifications to the exhaust or intake will change the noise level of your scooter/kart which will disturb others. Making changes or modifications to your scooter/kart can make your scooter/kart act or perform in a manner that is unsafe.

9.1 Brakes:

Side-pull caliper

Scooters/karts fitted with side-pull calipers operate much like a standard bike side pull caliper brake, with the exception that the wearing surfaces are incorporated into the tire rather than brake pads.

Fine Adjustment: **1)** Loosen the adjustment barrel locknut. **2)** Turn the adjustment barrel clockwise if brake rubs against the wheel, and counter clockwise if they are too far away. (Each side should be a 1/16" to 3/16" spacing between caliper and wheel) **3)** Securely tighten the locknut.

Major Adjustment: **1)** Loosen the adjusting barrel clockwise until it bottoms out, then back it off 1 1/2 or 2 turns. **2)** Loosen the cable anchor nut. **3)** Squeeze the brake arms together and hold them so the brake remains against the tire (3 hands make a big difference). **4)** Pull out all the slack on the cable using pliers. While maintaining cable tension with the pliers and still squeezing the brake arms together, tighten the cable anchor nut.

NOTE: It is not critical to have the both sides of brake calipers strike the wheel at the same time. It is possible for one side to reach the tire first. The other side will eventually strike the tire and the caliper will then squeeze the braking surface to slow the Go-Ped®. If one side of your caliper drags the wheel then adjust by using a 10mm deep socket to loosen the 10mm nut used to attach the brakes from the back side of the calipers. Hold the brakes straight and retighten in place. This operation is recommended to be performed by an authorized Go-Ped® dealer.

WARNING: The brake mounting bolts and nuts must be securely tightened to maintain proper braking.



Disc brake caliper

For your scooter fitted with disc brakes. The brake caliper must be replaced when the pads are worn less than the thickness of a dime.

Adjustment: **1)** Adjust the gap between rotor & outside pad with 3mm Allen driver via the center hole of caliper, turn clockwise to move pad forward and counterclockwise to move pad back. **2)** Adjust gap between rotor & inside pad with 5mm Allen driver via center bolt on back cover, turn clockwise to move pad forward and counterclockwise to move pad back.

Replacement of worn pads: **1)** Remove the caliper from fork using 5mm Allen driver (both brake lever adjustments barrels need to be screwed in all the way) **2)** Use pointed nose pliers or screwdriver to remove safety clip from pad guide. **3)** Loosen pad guide screw with 3mm Allen driver. **4)** Remove complete pad assembly with inner plate spring. (Careful not to bend or twist spring) **5)** Fit replacement pad onto spring plate. **6)** Insert pad/spring combination into pad slot and relocate guide screw. **7)** Fasten guide screw and push safety clip back into clip gap on guide screw. **8)** Adjust brakes as described in the mechanical safety check section.

Maintenance of disk brake caliper: **1)** Keep all surfaces clean and free of oil and debris. More detailed information available at www.goped.com

Rear compression brake

Some models use engine compression/resistance as a brake. The engine cut off switch can be used to slow and/or stop your scooter that uses the engine as brake. Some have a foot operated brake that does not require any adjustment. The foot operated brake requires that your rear wheel have proper tire inflation. Make sure that this brake is operating properly and replace if necessary.

Brake lever and cable: Make sure the cable is not frayed or kinked in any way and also check to be sure that the cable housing ends are securely seated. An adjustment is available at the brakes and you can increase or take up slack by screwing or unscrewing the adjustment barrel.

Proper maintenance and care of your equipment are key factors in reliability and safety. Only you can insure for the care and maintenance for your equipment but make sure all users understand the importance of properly maintained equipment, all safety warnings/cautions, and recommended user practice contained in this manual for the safety of your equipment and all those that use it.

8.2 Special Engine Maintenance:

There are a few things you can do to keep your Go-Ped® engine at its best performance and cleanliest for the environment.



WARNING: Due to High operating temperatures, make sure that the engine has stopped and is cool before performing any service to the machine.

A. Air Filter: Clean the Air Filter every 5 hours of operation. It is an important item to maintain. Failure to maintain your air filter properly can result in poor performance or can cause permanent damage to your engine.



CAUTION: Do not operate the engine without a properly maintained air filter attached.

- Clean the air filter using an appropriate air filter cleaner or wash filter in detergent and water. Rinse and allow to dry.
- Re-oil the air filter using an appropriate air filter oil. Lightly coat the filter. Do not over oil air filter.

For fabric type air filters: Lightly oil entire air filter element with air filter oil. Do Not Over Oil. Over oiling the air filter can restrict air flow and prevent your engine from running properly and become difficult to start. Only use Air Filter Oil as it is designed to help improve air filter performance.


B. Carburetor Adjustments: The idle speed of the engine is adjustable. An idle adjustment screw is on the side of the carburetor. Allow the engine to reach operating temperature before making any adjustments to the idle. Release throttle to let engine idle. If engine stops, use a small phillips screwdriver and turn the idle screw clockwise no more than 1/8 of a turn at a time until engine idles smoothly.

Note: Careless carb. jetting adjustments can seriously damage your unit. An authorized service dealer should make any necessary carburetor adjustments. Unauthorized tampering of carb. jetting will VOID your warranty.

Note: The condition of the air filter is important to the operation of the unit. A dirty or oil saturated air filter will restrict air flow. This is often mistaken for an out of adjustment carburetor.

C. Fuel Filter: When the engine runs short of fuel supply, check the fuel cap and the fuel filter for blockage. A slow to return carb. primer bulb is a good indication of a plugged fuel filter.

D. Spark Plug: Starting failure and misfiring are often caused by a fouled spark plug or flooded engine. Clean the spark plug and check that the plug gap is in the correct range (Correct plug gap is .024 - .026"). If flooded allow time for the excess fuel in the engine to evaporate.



CAUTION: Using any spark plug other than those designated by the manufacture of the engine may result in engine failing to operate properly or cause engine damage. To install the spark plug, first turn the plug until it is finger tight, then tighten a quarter turn more with a socket wrench. (87-104 in-lbs torque)

E. Muffler: Periodically inspect the muffler for loose fasteners, any damage, or corrosion. If any sign of exhaust leakage is found, stop using the unit and have it repaired immediately.

A. Know Your Scooter/Kart: Familiarize yourself with the scooter before you ride. Check the controls. Ride very cautiously until you become familiar with the way the scooter/kart handles. Take turns slowly and give yourself extra stopping distance.

B. Ride Within Your Abilities: To control your scooter, you need to keep it upright and make it go where you want it to go. This section cannot teach you how to control direction, speed or balance. Only a lot of practice will do that. Below are a few things to help you.

C. Body Position: Stand firm but relaxed. Keep weight between the wheels. Don't stand too close to the front or lean too far back. Shift your weight to the rear when applying brakes, and lean towards the front when accelerating. Keep feet apart for more stability.

D. Turning: New riders tend to have more trouble turning than experienced riders do. The only way to make good safe turns is to practice. Always approach turns very carefully.

E. Braking: Front brakes provide most of your stopping power, but you will need to learn to adjust your center of gravity to maintain stability. Again, practice this at a safe speed until you are comfortable with this action.

F. Areas to Ride: Ride in a safe place free of cars in an area which will not disturb other people or animals and has a clean dry surface.

2.4 Rules to Scoot By:

- Always wear your safety gear
- Never ride under the influence of alcohol or drugs
- Learn the local laws and regulations
- Ride defensively
- Wear bright colored and/or reflective clothing
- Never ride your scooter/kart at night or in conditions of poor visibility.
- Observe and yield the right of way
- Do not dart out of driveways or from between parked cars
- Stop at all stop signs/lights
- Be careful when checking traffic and don't swerve when looking over your shoulder
- Always go with traffic flow and keep to the far side of the road
- Never ride on sidewalks
- Avoid riding in bad weather or when visibility is obscured
- Do not do stunts, wheelies or jumps. They will increase your chances of injury and damage to your scooter/kart.
- You are sharing roads, trails and riding areas with others. Respect their rights, and be tolerant if they inconvenience you.
- Always yield right of way to pedestrians and animals. Ride in a way that does not frighten or endanger them, and avoid riding near them whenever possible.
- Keep your speed consistent with the conditions, and keep in mind that speed has a direct relation to control as well as component stress.
- Never carry passengers.
- Never carry anything that can obstruct vision, or control of your scooter.
- Everyone must be responsible for the environment, ride accordingly.

2.5 Stunts, Wheelies, or Jumps: These stunts can be fun, but it puts incredible stress on everything. Riders who insist on jumping risk serious damage to their scooter/kart and themselves.

2.6 Wet Weather Riding: Riding in wet conditions is not recommended.

WARNING: Wet weather impairs traction, braking and visibility, for riders and others. The risk of accident dramatically increases in wet conditions and should be avoided.



2.7 Night Riding: Never ride your scooter/kart at night or in conditions of poor visibility.



WARNING: Riding at dawn, dusk, or at times of poor visibility is illegal and dangerous.

Section 3: Assembly

3.1 Pre-Assembled Scooters.

Some models come completely and fully assembled so there is no assembly requirement. Remember to do a Mechanical Safety Check and make final adjustments to hand levers, and drive components. Oil chain and air filter if needed.

3.2 Some Assembly Required.

Some models shipped in the box partially assembled. Before doing any final assembly do an inspection of all components to insure that nothing was damaged during shipment. If you see any damage or stressed components then contact your local authorized dealer for replacements or repairs to those components. After assembled, remember to do a Mechanical Safety Check and make final adjustments to hand levers, and drive components. Oil chain and air filter if needed.

A. Front Wheel

1. Remove bolt and washers from end of front axle. **A1**
2. Remove front axle from front fork. **A1**
3. Insert brake disc into front brake caliper and align wheel with axle bushing on fork. **A2**
4. Insert axle through steering arm bushing and into wheel hub. It may be necessary to align inner wheel spacer between bearings to allow axle insertion. **A2**
5. Install axle and tighten axle bolt and nut. **A3**
6. Check for smooth wheel rotation and proper front brake actuation.

B. Rear Wheel

1. Remove axle nut and washers from end of rear axle. **A4**
 2. Install rear wheel with valve stem on left side to prevent interference with gas tank bracket. **A5**
 3. Rotate rear fender and tank mount bracket and align with rear axle.
- NOTE: Make sure fender doesn't rub wheel or interfere with drive components. A6**
4. Install axle bolt with washers between bearings and bracket and nut.
 5. Tighten rear axle bolt.
 6. Check for free rotation of rear wheel.
 7. Check for proper operation of rear brake if applicable.
 8. Check for proper operation drive component operation.



C. Pneumatic Tire Information

- Never use tires or tubes not recommended by Go-Ped® or P.M.W. or exceed the maximum P.S.I. limits of the tire assembly in use.
- For the Bigfoot and Super Bigfoot Use higher pressures in the rear (Use maximum P.S.I. rating as specified on side wall of wheel) for efficient drive system performance, and lower pressures in the front for a smoother ride characteristic.



WARNING: Never exceed P.S.I. rating specified on the side wall of your tire or serious injury can result. Never use nonstandard equipment as it may



of control, unstable conditions, and failure.

WARNING: Tire wear, punctures, or ruptures can cause immediate loss of control, which may affect operator and precipitate serious bodily injury.

WARNING: Many Go-Ped® service and repair tasks require special knowledge and tools. Do not begin any adjustments, service, or repair on your Go-Ped® if you have the slightest doubt about your ability to properly complete them. Improper adjustments, service, or repair may result in damage to the Go-Ped®, and/or accident.



WARNING: Any modification to this unit voids the warranty, including but not limited to: disconnecting the muffler exhaust tube, using either wheels or tires not recommended by PMW, changes to the emissions control systems, attempting to enhance the speed or performance of the engine, and/or equipping the unit with any non PMW/Go-Ped OEM components. Such modifications can create HAZARDOUS AND/OR DANGEROUS conditions for the rider, and can result in serious damage and personal injury.



8.1 Service and Maintenance Schedule

Some service and maintenance can and should be performed by the owner, and require no special tools or knowledge beyond what is in this manual. It is always a good idea to go over key points with an authorized Go-Ped® dealer who can further assist you with questions you might have and is an excellent source for your OEM replacement parts. In addition you will also find helpful information on service and maintenance at www.goped.com.

1. Break-In Period: Go-Ped engines are tuned for high-output and require proper care and maintenance. Proper engine break-in is critical to improving engine life and reliability in a brand new engine. During the Break-In period is when engine components are seating to match one another, and allow engine oil in the fuel to properly coat interior components. Start with properly mixed and fresh fuel (We recommend you use a high quality Non-Synthetic 2-cycle oil for Break-In but it is not required). Once started run the engine at varying speeds for 3 to 10 minutes at a time but avoid using full throttle. Allow the engine to run at idle for 30 seconds to a minute so it can slowly cool before shutting off. Now allow engine to cool off completely for at least 10 minutes before repeating the process. Your engine should go through 3 to 4 heat cycles, allowing the engine to cool each time before you start using full throttle and normal operation. After Break-In it is recommended to switch to a high-quality synthetic 2-stroke oil in the fuel.

2. Before Every Ride: Do a "Mechanical Safety Check" (Section 2.2). Lube/adjust chain or drive wheel (depending on model). Lift the front wheel off the ground and turn from side to side and wiggle back and fourth. **If the steering feels loose or sloppy do not ride and have an authorized Go-Ped® dealer check it.**

CAUTION: Go-Ped® scooters are equipped with a mechanical "fuse" incorporated into the lower folding handlebar hinge assembly which is designed to fail before a catastrophic failure. If your "t" handle feels abnormally loose or sloppy you must immediately stop riding and have the scooter serviced. Failure to ignore this safety feature could result in a catastrophic failure causing a sudden loss of control.



Inspect the brakes: Make sure you have sufficient brake pad life (more than the thickness of a dime). Models with solid rubber tires should have side wall grooves on the tire deeper than the thickness of a dime. Insure that brake caliper braking surfaces are completely contacting the braking services of the wheel or disc.

3. During and After Any Long Ride: Clean air filter, adjust and oil chain or make rear wheel adjustments as needed. Its a good idea to perform a Mechanical Safety Check and wipe away any collective dirt or debris.

4. Every 25 to 50 Hours of Operation: Your Go-Ped should have a complete checkup by an authorized Go-Ped® dealer so that any component can get retightened, adjusted, replaced, or repaired as necessary.

6.6 Motorized Riding



WARNING: The exhaust contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

Warm up the engine (30 to 60 seconds). With the Sport, X25, X-Ped®, and Super X-Ped™ engine running and with throttle set at idle, set the rear tire on the ground and immediately start walking alongside the scooter then step on the deck with both feet and with both hands firmly on the handle grips you can now begin to add throttle control. This will take some practice and coordination before you can do it smoothly. With the GSR/GTR you simply stand on the scooter with both hands on the controls, release the brake, and you can now apply throttle control. With the Bigfoot™ you have both hands on the controls and push off or get a push from an assistant. While the scooter or kart is rolling, slowly lower the motor using the trim lever to engage the drive spindle against the tire while slowly applying more throttle.



WARNING: The scooters and kart outlined in this manual use a friction and/or a chain drive system. Keep clear of rear wheel and its drive components when the engine is running or severe injury may occur.



CAUTION: As engine power is applied through a friction or chain drive, it is very important to maintain proper drive roller/chain tension adjustment as outlined in this manual.

Section 7: Free Wheel Scooting

7.1 Non-Chain Driven Models

Unlock the rear wheel quick release lever. Pull wheel down to bottom of axle adjustment slot. Rotate EPW to contact lug and lock down Quick Release Lever. Check for free rotation of rear wheel. Riding in this mode should be legal anywhere bicycles are allowed.

NOTE: Rear wheel adjustment will be required more frequently when tire is new, to prevent drive system slippage. If drive system is allowed to slip excessively, high temperatures will result and damage the drive spindle and/or tire, extreme or uneven tire wear will also result, causing uneven overloading to engine crankshaft and bearing. Refer to section 9.2 "Adjusting the rear wheel" in this manual to correct drive system engagement issues.

7.2 Bigfoot™

To disengage the drive system for free wheeling simply adjust the engine trim lever to the disengaged position.

7.3 Chain Drive Models

With engine not operating simply push the scooter.

Note: There will be some natural resistance caused by the drive components.

Section 8: Maintenance and Parts



CAUTION: Technological advances have made Go-Ped® and the components more complex than ever. This on going evolution makes it impossible for this manual to provide all the information required to properly repair and or maintain your Go-Ped®. In order to help keep your unit functioning normally, you have any repair or maintenance which is not specifically described in this manual performed by an authorized Go-Ped® dealer.

Just as important is that your individual maintenance requirements will be determined by everything from your riding style to geographic location. Consult your authorized Go-Ped® dealer for help with determining your individual maintenance requirements.

NOTE: Failure to maintain your unit at the recommended schedule may result in poor performance and/or cause permanent damage to your engine.

WARNING: Patching a tube is an emergency repair. Patches can severely weaken the integrity of a tube, resulting in possible tube failure and cause a loss of control. Replace a patched tube as soon as possible. Never replace the tube with anything other than the stock OEM tube. Using an aftermarket tube or tire not intended for Go-Ped® specification could result in a sudden loss of pressure that could cause damage to your scooter and sudden loss of control. Never use a tube or tire that is not recommended by Go-Ped®.




CAUTION: Replace front or rear tires when tread is worn within 1/16" tread depth, or if obvious tire damage has occurred.



D. Non-Pneumatic Tire Information

Non-pneumatic tires require no maintenance but must be replaced when normal wear and tear makes the tire diameter reach the wear limit dimple found on the side wall of the tire. Split, cracked or torn tires should be replaced immediately.

E. "T" Handle Installation



1. Remove the plastic hinge pin from the bottom of the handle bar assembly.
2. Compress slide tube locking spring and hold in place.
3. Insert the handle bar assembly in the slot of the lower hinge assembly found on the body of the frame assembly at the front fork.
4. Hold the slide tube in the up position and insert the plastic hinge pin.
5. Use a hammer and a spare bolt (not provided) to get the plastic hinge pin centered in the hole so that the slide tube can slide over it and sit flush with the bearing race. **Note: Refer to "3.3 Folding Feature" for proper operation.**

3.3 Folding Feature

Your Scooter is equipped with a folding feature for easy carrying and stowage. To fold pull up against the spring tension on the slide tube found on the base of the "t" handle until it completely exposes the hinge assembly and fold to the latching mechanism found next to the motor. Reverse process to lock handle bar in the riding position. **Note: Karts do not have a folding feature.**

WARNING: The "Lower Hinge" of the folding hinge assembly is also a "Mechanical Fuse" designed to break if there is high shock loads, stress, and/or fatigue exerted on the handlebar assembly. The lower hinge is a safety feature that will leave your bars extremely loose and must be replaced before you continue to operate the unit.



A. Adjustment of Slide Tube Clamp:

The slide tube clamp on the bottom of your Pro Slide Tube is used on extreme performance Go-Peds to reduce handlebar play at the hinge. Adjustment of the clamp is a simple operation, which is performed using a 5mm allen wrench.

- If the clamp is left loose, the slide tube can easily slide up so that the scooter may be folded.
- If the clamp is very tight, it will not be possible to slide the tube up and fold the scooter.
- The clamp will reduce play even when the bolt is not very tight. The play will be reduced more as the bolt is tightened.
- The rider should determine the setting which works best for them.

CAUTION: Before you ride - Be certain the handle lock tube is in its full down position, locking the handle bar upright, and that the lower hinge does not feel loose or appears to be sliding out.



Section 4: Oil & Fuel Information

Your Go-Ped® has a two-stroke engine requires two-cycle oil to be mixed with gasoline. Use a high quality 2 cycle oil that is formulated for small air cooled engines.

NOTE: Go-Mix II oil packets are formulated to reduce engine emissions, extend engine life and are recommended and available through your authorized Go-Ped® dealer. Go-Mix II is pre-measured for US gallon or goped® tank sizes and does not require measuring. Due to the high quality and formulation of this oil, it is not necessary for Go-Mix II oil to match specific engine oil/gas ratios. It does require that you double the dosage of oil packs for models with a 25:1 fuel/oil ratio or those with engine modifications.

4.1 Oil and Fuel Mixing Instructions



CAUTION: For proper engine operation and maximum reliability, pay strict attention to the oil and fuel mixing instructions. Using improperly mixed fuel can severely damage the engine. Please refer to the list below for proper oil mixture.

Engine	Fuel / Oil Ratio	Ounces of oil per U.S. gallon
G23LH	40:1	3.2 oz.
GZ25N14	50:1	2.65 oz.
GZ25N23	50:1	2.65 oz.
GP290RS	25:1	5.12 oz.
G43L-D	50:1	2.65 oz.
GP420RS	25:1	5.12 oz.
GP460RS	25:1	5.12 oz.
GPL290	40:1	3.2 oz.



Use the following procedure to ensure proper mixing:

- 1) Put a small amount of fresh gasoline (91 octane or greater) into a clean 1(U.S.) gallon (3.875-liter) fuel can.
- 2) Add 2 cycle oil (Use chart for proper ounces of 2-cycle oil.)
- 3) Fill the remainder of the fuel can with gasoline (1 U.S. gallon).
- 4) Screw the fuel can cap on tight and SHAKE THE CAN VIGOROUSLY FOR 30 SECONDS.



Note: Go-Mix oil packets are specially formulated for lean mix ratios in two-cycle motors. Go-Mix Oil has excellent lubricity and cleanliness properties to control friction and prevent wear, plug fouling, ring sticking and exhaust port blocking. Go-Mix is “smokeless” and delivers fewer emissions at 100:1 mix ratios than oils mixed at 50:1 or higher and ok to use at recommended ratio in your Go-Ped® scooter or kart.



WARNING: Operate this unit only in a well-ventilated area - outdoors. Carbon monoxide exhaust fumes can be lethal in a confined area. The exhaust contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

4.2 Fueling & Pre-Operation

- Gasoline is extremely flammable and its vapors can explode if ignited. Always stop the engine and allow to cool before filling fuel tank. Keep sparks and open flames away from the area.
- Add fuel in a clean, well-ventilated area. Avoid spilling the fuel when mixing the oil. Wipe up spills immediately. If fuel has been spilled allow to dry completely before starting the engine.
- Move the unit at least 10 feet (3m) from the fueling point before starting the engine.
- Pressure can build up in the fuel tank. Loosen the fuel tank cap slowly to relieve pressure.
- Store fuel only in containers designed and approved for the storage of such materials.

Section 5: Controls

CAUTION: Before you ride - Familiarize yourself with how your Go-Ped® works.



- Familiarize yourself with which levers operate the brakes and throttle. Your new scooter or kart may be different than other dirtbikes, ATV's, bicycles, watercraft, etc. which you may have ridden before.
- Some scooters are fitted with a rear foot pedal that operates the rear wheel brake.
- The red button is the engine kill switch. The kill button can be used as a brake on the Sport, S25, X25, X-Ped and Bigfoot models. **B3**
- For the Bigfoot™ the engine trim lever controls the engagement of the drive spindle to the rear wheel and can also be used for freewheeling or to keep engine running while your Bigfoot™ is not in motion. Note: Kill button cannot be used as a brake in this mode.
- The handle bar or steering wheel supports the rider and steers the Go-Ped®.
- Always use both hands on the handle bar, when riding.



Section 6: Starting

BEFORE YOU RIDE - Your Go-Ped® scooter or kart should be properly warmed up.

6.1 Starting your non-chain driven model

These scooters are equipped with a direct friction spindle drive system that is extremely efficient with just one moving part. With proper contact to the tire, the tire will only spin when the engine is turning or running (see “Free Wheel Scooting” to disable the drive). In order to start your sport for the first time follow the directions as shown in “Engine Starting Instruction” (section 6.5), you must have the rear wheel off the ground or the scooter will jump forward. To get the rear wheel off the ground, simply lay over to one side with your foot underneath the scooter to help raise the rear wheel off the ground.

6.2 Starting your chain drive models

Your chain drive unit is equipped with a centrifugal clutch that will engage when engine RPM reaches a certain point. To prevent the scooter from suddenly jerking forward when the clutch engages make sure that the rear wheel is off the ground and front brake fully engaged when starting/warming up. To start follow the directions as shown in “Engine Starting Instruction” (section 6.5).

6.3 Starting your Bigfoot™

These Scooters use a friction spindle drive system. To start simply trim the motor up on the Bigfoot™ so the spindle is not engaged to the wheel. Use the side kick stand to keep the Go-Ped® from falling over and follow the directions as shown in “Engine Starting Instruction” (section 6.5).

6.4 “Easy Pull” pull starter

Some engine models are designed with a easy start and “easy pull” pull starter that only requires a few gentle pulls to start. If the engine does not start check fuel, choke lever position, and clear possible engine flooding or fouling before continuing. Pulling aggressively or continually only puts unnecessary stress on the pull starter that can harm it.

6.5 Cold Engine Starting Instructions

- 1) Pump primer bulb until fuel flows steadily through clear yellow return tube.
- 2) Move choke lever to the closed position.
- 3) Do not apply throttle or you may need to use just a small amount of throttle to start.
- 4) Pull starter until engine starts and then position choke back to open.
- 5) Allow engine to warm up to operating temperature before using (about a minute).
- 6) To stop, idle engine, push red kill button. Warm engines do not require choke.